Page 2 SI-6-18-10-A

## MAINTENANCE



Components are under pressure. Relieve air pressure before performing any maintenance. Rotate regulator knob fully counter-clockwise to relieve regulator spring pressure.

## PARTS LIST

Ref. No.	Replacement Part No.	Description
1	130521	Regulator Kit
2	VA-594	Shut-off Valve
3	GA-288	Gauge

