



PARTS LIST

Ref. No.	Description	Part Number	Qty.	Options
1	Air Cap/Retaining ring	SP-100-***-K	1	505, 510 e.g *** = 510
2	Nozzle	SP-200S-**-K	1	10, 12, 13, 14, 16, 18, 20 e.g ** =14=1.4 mm
+3	Separator	SP-623-K5	5	
+4	Packing	GTI-445-K2	2	
5	Spreader Valve	SP-401-K	1	
6	Stud and Screw			
7	Needle Adjusting Screw	SP-614-K	1	
+8	Spring	SP-622-K5	1	
9	Needle	SP-300S-**-K	1	10, 12, 13, 14, 16, 18, 20 e.g ** =14=1.4 mm
10	Airvalve housing & seal	SP-612-K	1	
11	Spindle		1	
12	Trigger, Stud & Screw Kit	SP-617-CR-K	1	
13	Connector	SP-611-K	1	
14	Airflow Valve	SP-402-K	1	
15	Fluid Inlet Connector and seal	SP-636-K	1	
16	Air Valve Service Kit	SPK-101-K	1	
17	Retaining Ring and Seals	SPK-102-K	1	
+18	Clip, Seal and Pin Kit	GTI-428-K5	5	
20	Air Valve Assembly Tool		1	
21	Spanner	SPN-5-K	1	
	Spraygun Service Kit (parts included marked +)	SPK-402-K	1	